

Guida QUADRO ad estrazione parziale PUSH TO OPEN. Portata: 25kg. Utilizzare gli agganci: 05.0102HA

Partial extension PUSH TO OPEN slide. Load capacity: 25Kg. Clips: 05.0102HA

hettich



COD.	DESCRIZIONE / DESCRIPTION	
05.9099969000	GUIDA QUADRO 25SFP/500-EB20 P2O PARZ.SX / LEFT DRAWER SLIDE 25SFP/500-EB20 P2O	24
05.9099970000	GUIDA QUADRO 25SFP/500-EB20 P2O PARZ.DX / RIGHT DRAWER SLIDE 25SFP/500-EB20 P2O	24
05.F909995700	GUIDA QUADRO 25SFP/300-EB20 P2O PARZ.SX / LEFT PART.EXT.PUSH SLIDE 25SFP/300 EB20	48
05.F909995800	GUIDA QUADRO 25SFP/300-EB20 P2O PARZ.DX / RIGHT PART.EXT.PUSH SLIDE 25SFP/300 EB20	48
05.F909996100	GUIDA QUADRO 25SFP/350-EB20 P2O PARZ.SX / LEFT PART.EXT.PUSH SLIDE 25SFP/350 EB20	120
05.F909996200	GUIDA QUADRO 25SFP/350-EB20 P2O PARZ.DX / RIGHT PART.EXT.PUSH SLIDE 25SFP/350 EB20	120
05.F909996500	GUIDA QUADRO 25SFP/400-EB20 P2O PARZ.SX / LEFT PART.EXT.PUSH SLIDE 25SFP/400 EB20	24
05.F909996600	GUIDA QUADRO 25SFP/400-EB20 P2O PARZ.DX / RIGHT PART.EXT.PUSH SLIDE 25SFP/400 EB20	24
05.F909996700	GUIDA QUADRO 25SFP/450-EB20 P2O PARZ.SX / LEFT PART.EXT.PUSH SLIDE 25SFP/450 EB20	24
05.F909996800	GUIDA QUADRO 25SFP/450-EB20 P2O PARZ.DX / RIGHT PART.EXT.PUSH SLIDE 25SFP/450 EB20	24



NL - 12 mm

NL mm	≥ KT mm	EL mm	b1 mm
250	263	50	160
300	313	50	160
320	333	62	192
350	363	62	192
380	393	62	224
400	413	74	224
420	433	74	224
450	463	86	256
480	493	86	256
500	513	98	288
520	533	98	288
550	563	98	320

